

Exploded View

Put the square neck washer onto the carriage bolt first, then put the bolt through the L-bracket and secure with the plastic knob.

L-brackets are mounted to rear of mower deck.

Rubber sheet is mounted between two metal plates using four bolts/nuts.

FRONT

Small metal plate should be between the rubber sheet and the L-brackets.

REAR

Large metal plate should be between the rubber sheet and the plastic knobs.

